

16200 - Combi5xx - Combi422 Series - New Fw v 2.14

Bugs fixed (vs previous FW release)

- None

Modifications (vs previous FW release):

- **Label change:** from "RCD/RCCB" to "RCD Type"
- **Possible parameter values:** "RCD", "RCCB", "RCDHiS"

Additional Notes:

- **"RCDHiS"** Highly Sensitive RCD, which will result in the circulation of the following currents:
 - **"Ut" and "Ra no Trip" (also for Autoseq):** $I_{\text{test}} \sim 0.65 \times I_{\text{dn}}/2$ (for all types of AC/A/F/B).
 - **"Test x5":** $I_{\text{test}} = I_{\text{dn}} \times 5$ for Type AC, $I_{\text{dn}} \times 5 \times 1.414$ for Type A/F.

16200 - Combi5xx - Combi422 Series - New Fw v 2.12

Modifications (vs Fw v 1.24)

- HARM: now App HT Analysis displays correctly also fundamental value (100%)

Bugs fixed (vs previous Fw release)

- HARM: values Fixed bug about harmonic order indicated when calling this page for 1st time
- LOOP: fixed bug about data type indication (direct mode)

Additional Notes:

Note : This Fw release requires latest Topview version

16200 - Combi5xx - Combi422 Series - New Fw v 2.11

Modifications (vs previous Fw release)

- Ra No Trip Loop: Improved Test immunity against electrical noise
- DV%: Z1 value was lost after instrument turning off. Now Z1 value is kept after turning off/on the instrument.
- General settings: introduced LCD Contrast adjustment

Bugs fixed (vs previous Fw release)

- none

Additional Notes:

Note : This Fw release requires latest Topview version